




# Troubleshooting




Your boomerang should fly more or less like depicted above. Some models fly higher with a nice a hover at the end.




Throw further to the right (relative to the wind). On calm days: Throw with reduced layover.




Use less tilt. Never throw your boomerang sidearm! Hold your boomerang vertically with no layover.



Throw further to the left (relative to the wind). On calm days: Throw with more layover.




Aim a bit lower. If this won't help, throw with more power and/or spin.



Throw with more power and/or spin. Try throwing lower or with a little more tilt.



Aim much lower!



Throw with less power or less tilt.